Zero Turn Core Plugger

Optional Clamp-on Mount Shown

Drill and bolt C-Mount Bracket

Install end caps with anti-rotation pins against the mount brackets.

Drill 2 holes through caster arm frame on each side and install C- mounting brackets

Country Manufacturing, Inc.
P.O. Box 104 333 Salem Avenue
Fredericktown, Ohio 43019
Phone: (740) 694-9926
Fax: (740) 694-5088
Web Site: www.countrymanufacturing.com

Note: The anti-rotation pins must be placed with the pin at the top of the bracket so it pushes the unit down as you move forward.